

Changing the Ozone Calibrator Levels 49I Ozone Analyzer

NOTE: Close iPort before changing the levels.

1. Push the "MENU" button
2. Use the down arrow button until you see "Instrument Controls" and then press "ENTER"
3. Use the down arrow button until you see "Custom Levels" and then press "ENTER"
4. In the Custom Levels menu there are 5 level options; you only need to set Level 1 and Level 2 (skip the other levels when you are running a calibration)
5. To set Level 1, select it by hitting the "ENTER" button
6. Using the up and down arrow button, change the percentage(%) by increasing or decreasing the % so that Level 1 equals about **40ppb** and then press "ENTER"
 - a. **NOTE:** When changing the percentage you must wait 30-60seconds per increase/decrease of percentage for the ozone (ppb) to stabilize to decide if the percentage is a true reading of ~40ppb
7. Repeat for Level 2 and set Level 2 equal to **80ppb**. Press the return arrow button ("Save Value") to save the new setting
8. Then press "RUN" (this should take you back to the main menu screen from where you will run the different levels)