

MOSAIC Tower MOXA Settings

Ozone sampler:

Network Settings

IP address	192.168.2.20
Netmask	255.255.255.0
Gateway	
IP configuration	Static
DNS server 1	
DNS server 2	

Serial Settings

Port 01	
Port alias	
Serial Parameters	
Baud rate	9600
Data bits	8
Stop bits	1
Parity	None
Flow control	None
FIFO	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Interface	RS-232 Only

Operating Settings

Port 01	
Operation mode	TCP Server Mode
TCP alive check time	7 (0 - 99 min)
Inactivity time	0 (0 - 65535 ms)
Max connection	1
Ignore jammed IP	<input checked="" type="radio"/> No <input type="radio"/> Yes
Allow driver control	<input checked="" type="radio"/> No <input type="radio"/> Yes
Data Packing	
Packing length	20 (0 - 1024)
Delimiter 1	0 (Hex) <input type="checkbox"/> Enable
Delimiter 2	0 (Hex) <input type="checkbox"/> Enable
Delimiter process	Do Nothing (Processed only when Packing length is 0)
Force transmit	0 (0 - 65535 ms)
TCP Server Mode	
Local TCP port	4001
Command port	966

Picarro:

Network Settings

Network Settings	
IP address	192.168.2.21
Netmask	255.255.255.0
Gateway	
IP configuration	Static
DNS server 1	
DNS server 2	

Serial Settings

Port 1	
Port alias	
Serial Settings	
Baud rate	19200
Data bits	8
Stop bits	1
Parity	None
Flow control	None
FIFO	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Interface	RS-232

Operation Modes

Port 1	
Operation mode	TCP Server
TCP alive check time	7 (0 - 99 min)
Inactivity time	0 (0 - 65535 ms)
Max connection	1
Ignore jammed IP	<input checked="" type="radio"/> No <input type="radio"/> Yes
Allow driver control	<input checked="" type="radio"/> No <input type="radio"/> Yes
Local TCP port	4001
Command port	966
Data Packing	
Packing length	20 (0 - 1024)
Delimiter 1	00 (Hex) <input type="checkbox"/> Enable
Delimiter 2	00 (Hex) <input type="checkbox"/> Enable
Delimiter process	Do Nothing (Processed only when packing length is 0)
Force transmit	0 (0 - 65535 ms)